

HOW TO READ YOUR METER



The Township of Southgate will read your meter for billing purposes, but **should you wish to monitor your own consumption**, here's how:

- ◆ Shine a flashlight over the flashlight icon (located on the register) to turn the LCD display on
- ◆ Take a reading at a set time of the day
- ◆ Take a 2nd reading at the same time the next day
- ◆ The difference between the two readings is your daily water consumption

Leak Indicator

– displays a possible leak

- ◆ **OFF** – indicates no leaks
- ◆ **Flashing** – water usage for more than 50% of time in 24 hour period
- ◆ **Continuous ON** – there is most likely a leak in your home



The 9 digit LCD displays your meter reading in cubic meters

The last 4 digits of the reading are decimal points. (e.g. – 26.3987 cubic meters)

Flow Indicator

– displays direction of water flow

- ◆ **ON** – water in use
- ◆ **OFF** – water not in use
- ◆ **Flashing** – water is running slowly
- ◆ **(–)** – indicates reverse flow
- ◆ **(+)** – indicates forward flow